

Main Features

- User-Friendly
- Large, Easy-To-Read LCD
- Auto-Calibration
- Automatic Temperature Compensation
- All Push-Button Operation
- Bouyant, IP67 Waterproof Housing

Economy
Waterproof Testers

EcoTestr Series



Click-Lock Battery Compartment

Simply lift and remove cover to replace batteries. No additional tools required.

Pocket Clip secures tester firmly to your belt or pocket



Easy To Use

Push-button operation with clearly assigned keypad makes tester a breeze to use.

Tactile Switch Keypad lasts longer than ordinary keypad



IP67 Waterproof

Lightweight tester floats on water for easy retrieval.



Transparent Protective Cap

Doubles up as a container for sensor conditioning or on-site calibration.



Non-Volatile Memory

Retains tester settings even when batteries run out – no need to recalibrate each time you change batteries.

Large, Upright LCD

With parameter display and battery level indicator for easy reading.

Easy Push-Button Calibration

Microprocessor-powered tester requires no screwdriver for calibration. Simply immerse sensor in calibration solution, pause for reading to stabilise and press "CAL"!

Automatic pH Calibration

Calibrating your EcoTestr pH Series is a breeze with the auto-calibration feature! Switch tester to calibration mode, immerse sensor in pH buffer solution and leave tester to do the rest

Automatic Temperature Compensation*

Adjusts readings according to temperature change automatically for greater accuracy.

** For EcoTestr pH 2 only*



Eutech Economy Waterproof Testers Specification Tables





Warranty | Warrantied against manufacturing defects for a period of ONE year from date of purchase.



Eutech reserves the right to make changes, improvements and modifications to products shown.

pH Waterproof Testers		eco Testr pH 2		eco Testr pH 1	
					
pH	Range	0.0 to 14.0 pH			
	Resolution	0.1 pH			
	Accuracy	±0.1 pH			
	Calibration	3-point ; automatic		1-point ; automatic	
	Automatic Temperature Compensation (ATC)	Yes		-	
Tester Features	Non-Volatile Memory	Yes			
	Hold Function	Yes			
	Auto-Off	8.5 mins after last key press			
	LCD Display	3½ digit with annunciator			
	Power	4 x 1.5 V 'A76' micro alkaline batteries			
	Operating Temperature	0 to 50 °C			
	Ingress Protection	IP67 rating ; waterproof			
Dimension (LxWxH) ; Weight	Tester	16.3 x 4.5 x 3 cm ; 90 g			
	Packed	24.5 x 13.5 x 4.5 cm ; 137 g			

EC Waterproof Testers		eco Testr EC HIGH		eco Testr EC LOW	
					
Conductivity	Range	.. to 19.90 mS/cm		.. to 1990 µS/cm	
	Resolution	0.1 mS/cm		10 µS/cm	
	Accuracy	±1 % full scale (±2 % above 10 mS/cm)		±1 % full scale	
	No. Of Cal Points	1			
	Calibration Method	Digital, push button			
	Automatic Temperature Compensation (ATC)	Yes			
Tester Features	Non-Volatile Memory	Yes			
	Hold Function	Yes			
	Auto-Off	8.5 mins after last key press			
	LCD Display	3½ digit single line			
	Power	4 x 1.5 V 'A76' micro alkaline batteries			
	Operating Temperature	0 to 50 °C			
	Ingress Protection	IP67 rating ; waterproof			
Dimension (LxWxH) ; Weight	Tester	16.3 x 4.5 x 3 cm ; 90 g			
	Packed	24.5 x 13.5 x 4.5 cm ; 137 g			